


# A Risk Based Cleaning and Disinfection Program



Jim Polarine Jr. MA.  
Senior Technical Service  
Manager  
May 22, 2019



# Topics Covered

- **Regulatory Requirements**
- **Cleaning and Disinfecting Technologies**
- **Cleaning and Disinfection Techniques**
- **Rotation and Residues**

## USP 41 <1072> Disinfectants and Antiseptics:

**“A sound cleaning and sanitization program is needed for controlled environments used in the manufacture of Pharmacopeial articles to prevent the microbial contamination of these articles. Sterile drug products may be contaminated via their pharmaceutical ingredients, process water, packaging components, manufacturing environment, processing equipment, and manufacturing operators”**

PDA TECHICAL REPORT #70 “Cleaning and Disinfection Programs from Aseptic Manufacturing Facilities”:

“The purpose of the cleaning and disinfection program is not only to control microbial contamination but also to serve as a corrective action for the loss of control for viable excursions contamination. While the destruction of viable cells are an integral part of the cleaning and disinfection program, the use of disinfection as a singular focus without efforts to control contamination from entering the area is without technical merit. Environmental monitoring (EM) evaluates the efficacy of controls on the manufacturing environment. It is through control of bioburden levels entering the area, along with cleaning and disinfection, that acceptable viable control of the manufacturing or appropriate testing environment is achieved. “

## Disinfection

568

569 5.31 The disinfection of clean areas is particularly important. They should be cleaned and  
570 disinfected thoroughly in accordance with a written programme (for disinfection to be  
571 effective, cleaning to remove surface contamination must be performed first)., More than one  
572 type of disinfecting agent should be employed, and should include the periodic use of a  
573 sporicidal agent. Disinfectants should be shown to be effective for the duration of their in use  
574 shelf-life taking into consideration appropriate contact time and the manner in and surfaces  
575 on which they are utilized. Monitoring should be undertaken regularly in order to show the  
576 effectiveness of the disinfection program and to detect the development of resistant and/or  
577 spore forming strains. Cleaning programs should be effective in the removal of disinfectant  
578 residues.

579

580 5.32 Disinfectants and detergents should be monitored for microbial contamination;  
581 dilutions should be kept in previously cleaned containers and should only be stored for  
582 defined periods. Disinfectants and detergents used in grade A and B areas should be sterile  
583 prior to use.

584

585 5.33 Disinfectants should be shown to be effective when used on the specific facilities,  
586 equipment and processes that they are used in.

587

588 5.34 Fumigation or vapour disinfection of clean areas such as Vapour Hydrogen Peroxide  
589 (VHP) may be useful for reducing microbiological contamination in inaccessible places.

# Recent FDA WL

“Your firm used a broad-spectrum hard surface disinfectant that was not labeled as sporicidal or sterile as the sole sanitizing agent for sanitizing the ISO 5 classified area.”

FDA WL 2/11/19.

<https://www.fda.gov/ICECI/EnforcementActions/WarningLetters/2019/ucm631353.htm>

# Recent FDA WL: Cleaning and Disinfection

- “A. (b)(4) and (b)(4) cleaning and disinfecting solutions used in the critical processing zones and direct support zones are made with non-sterile tap water and held in non-sterile bottles that are used at (b)(4) per the cleaning procedure (FRAN-SOP002).
- B. your firm’s preparation and use of a (b)(4) solution during (b)(4) cleaning and disinfecting of the Class 10,000 cleanrooms and Class 100 laminar flow hoods where sterile saline/heparin filled syringes are manufactured has not been validated.
- C. the adequate removal of residues of disinfecting and cleaning solutions in the Class 100 laminar flow hoods has not been validated.”

FDA WL 9/14/18

<https://www.fda.gov/ICECI/EnforcementActions/WarningLetters/ucm622651.htm>

# Recent WL on Cleaning and Disinfection

“1. Your firm failed to use adequate contact times for sporicidal agents used as part of your disinfection program for the aseptic processing area.

1. Your firm failed to establish an adequate system for cleaning and disinfecting the room and equipment to produce aseptic conditions. 21 CFR 211.42(c)(10)(v)

1. Your response did not include any supporting documentation related to the review and revision of your cleaning procedure to address the inadequate contact time you use for sporicidal agents.”

FDA WL March 1, 2018

<https://www.fda.gov/ICECI/EnforcementActions/WarningLetters/2018/ucm602078.htm>

# Cleanroom Contamination Control

“Your firm used non-pharmaceutical grade drinking water, obtained from a bottled water dispenser located in the break room of your facility, in the production of non-sterile stock solutions and non-sterile drug products. Our investigators determined that the water was used in the production of dozens of drug products. During the inspection, our investigators collected a sample of the water obtained from the dispenser. FDA analysis of the (b)(4) identified the presence of *Burkholderia cepacia*, which is considered an objectionable microorganism.”

FDA WL May 9, 2018

<https://www.fda.gov/ICECI/EnforcementActions/WarningLetters/2018/ucm607912.htm>

# Cleanroom Behavior

“Investigators observed an operator sitting with her upper body leaning into the ISO-5 classified area with the sleeves of her non-sterile gown resting directly on the work surface of the ISO-5 classified area, thereby providing a potential source of contamination”


FDA WL July 10, 2018

<https://www.fda.gov/ICECI/EnforcementActions/WarningLetters/2018/ucm613879.htm>

“no use of sporicidal disinfectant on surfaces inside aseptic filling room **(b)(4)**, although your environmental monitoring detected spore-forming organisms there; and”  
FDA WL 1/19/17.

# Cleaning and Disinfection: Product Selection

- EPA Classifications
  - Sanitizer
  - Disinfectant
  - Sterilizer (Sporicide)



# Cleaning and Disinfection: Product Selection


- Sanitizer
  - Proper use results in bacteria reduction of >99.9%
  - 3-Log reduction
  - Used on precleaned surfaces unless tested with serum load

# Cleaning and Disinfection: Product Selection

- Disinfectant
  - Proper use results in 100% kill of vegetative bacteria, target viruses and target fungi
  - <https://www.epa.gov/test-guidelines-pesticides-and-toxic-substances/series-810-product-performance-test-guidelines>
  - May or may not require pre-cleaning
    - Serum efficacy - 5% BSA and EN methods differ example: skimmed milk as a soil load

# Cleaning and Disinfection: Product Selection

- Sterilant
  - Proper use results in 100% kill of all microorganisms, including bacterial endospores (*B. subtilis*, *C. sporogenes*)
  - Always requires pre-cleaning
    - Water quality is important




# Review - Microflora in Cleanrooms (U.K.)

- Tim Sandle
- PDA J Pharm Sci and Tech 2011, 65:392-403
- **A Review of Cleanroom Microflora: Types, Trends, and Patterns**
- Examined isolates from 2000-2009 in U.K.
- Grade A/B and C/D

# Review - Microflora in Cleanrooms (U.K.)

## Grade A and Grade B microflora by group, 2001-2009



## Review - Microflora in Cleanrooms (U.K.)


Genus	A/B (6729)	C/D (2500)
<i>Micrococci</i> (and related)	38%	40%
<i>Staphylococci</i>	21%	11%
<i>Bacillus</i> (and related)	13%	10%
<i>Pseudomonas</i> (and related)	<1%	8%
<i>Corynebacterium</i> (and related)	3%	5%
<i>Rhodococci</i>	<1%	N/A
Fungi	N/A	3%

# *Staphylococcus haemolyticus*



Courtesy Grace Thornhill

# Aspergillus Spores





# Cleanroom Fungi




Courtesy Dan Klein

# Aspergillus Spores





Courtesy Bruce Ritts

# SEM: Pseudomonas 5,000X magnification



# Bacillus Subtilis



Courtesy Bruce Ritts

# Biofilms



Courtesy Dan Klein

# Chemistries & Frequency

# Purpose of Cleaning and Disinfection

## Control microbial contamination


- Destruction of viable cells

## Corrective action for loss of control

- Viable and non-viable excursions

## Disinfection used in conjunction with contamination control program

- Prevent contamination from entering the room



# Cleaning and Disinfection

**Hospital Grade Disinfectants are formulated with surfactants, dispersants, and chelants to provide a moderate level of cleaning and microbial kill in cleanrooms.**


**Post construction and after worst case events either a triple cleaning or a double cleaning with a neutral or acidic cleaner would be recommended.**

# Disinfectant Components


Component	Function in Disinfectant
Water	Solvent
Antimicrobial	Kill, reduce microbes
Oxidants	Oxidize, kill microbes
Chelants	Tie up calcium, iron, stabilize oxidants, potentiates antimicrobial action
Solvents	Solubilization and stabilization of formula
Bases	Alkalinity source, hydrolysis (KOH)
Acids	Acidity source, hydrolysis (H <sub>3</sub> PO <sub>4</sub> )
Surfactants	Emulsification, Wetting

# Effect of Surfactants

- Influence of Surfactants on Wetting
  - Ability to displace particles
  - Penetrate soil and surface irregularities
  - Better contact



# Wetting Surface Tension and Penetration



# Contamination Control

## Control what enters your environment

- Viable and non-viable

## Begin with items transferred into facility

- Components, carts, personnel, tanks, tools, etc.
- Defined entrance procedures

## Good control leads to less

- Excursions
- Investigations
- Down time

**All items cleaned, sterilized or disinfected**  
*Highest level of decon possible*

Sterilization

OR

Automatic  
Disinfection  
(VHP)

OR

Manual  
Disinfection

# Chemical types

- Disinfectants and sanitizers
  - Phenolics
  - Quats
  - Alcohols
  - Hydrogen Peroxide 3%
- Sterilants and sporicides (potentially)
  - Sodium hypochlorite
  - Chlorine dioxide
  - Hydrogen peroxide 6%
  - Peracetic acid
  - Peracetic acid/hydrogen peroxide blends
  - Glutaraldehyde/formaldehyde
  - Ozone
  - Nitrogen Dioxide
  - Vaporized Peracetic Acid and VHP®



# Factors influencing performance

- pH
- Temperature
- Contact time
- Concentration
- Surface
- Presence of organic matter
- Water Quality (hardness)

# Tanks, Carts and Equipment

## Tank/Vessel

- If interior sterile, only address exterior

## Special attention to wheels

- Increased contact time
- Manual wiping



**Note:** *Captive carts (or commodity transfer in pass through) is HIGHLY preferred*

# Cleaning Supplies

## Chemicals

- Sterilizing filtration (.2 u)
- Gamma Radiation
- Autoclaving
- Pre-purchased sterile

## Mop heads/Sponges – Sterilized

## Other equipment

- Mops, buckets, squeegees, carts
- Sterilized (disinfected at a minimum)



# Manufacturing Components and Supplies

## Sterile components used in process

- Packaged in container that can be sanitized



## Spraying

- More wetting, no cleaning

## Mopping

- Mechanical action cleaning, less wetting

## Wiping

- For smaller surfaces, less wetting

## Fogging/Gassing

- Excellent efficacy, high residues, no cleaning

- Most critical areas to least critical areas
- Apply disinfectant to wiper or spray on the surface (garden variety sprayer)
- Changing out the use dilutions\* (2-3 Bucket routines)
  - 600 sq. ft (56 sq. meters) in ISO-5,6 (A & B)
  - 1,000 sq. ft (93 sq. meters) in ISO- 7,8 (C & D)
  - IEST-RP-CC018.4
- Grid (Blueprint of the Room)
- Pull and lift
- Overlapping strokes (by 20%)
- Figure 8 (also called figure S) or Unidirectional overlapping mopping strokes


\* Anne Marie Dixon, Ch. 11, Cleaning of Non-Product Contact Surfaces, p 226, *in* Cleaning and Cleaning Validation for the Pharmaceutical and Medical Device Industries, Vol. 1 Basics, Expectations, and Principles. Paul L. Pluta, Ed., PDA, Bethesda, MD, and DHI Publishing, LLC, River Grove, IL. 2009.

# Two Bucket System

- Sterilant (Disinfectant) in front bucket, optional to put some sterilant (Disinfectant) in waste bucket (bucket beneath the ringer)
- Dip mop head into front bucket, let excess liquid drain off, apply to the surface.
- When mop head appears to be dragging on the surface, dip into waste bucket, then wring out. Go back to front bucket and dip mop head, let excess liquid drain off and apply to the surface.
- Repeat above steps
  
- Other Mopping Systems: Single Bucket, Triple Bucket, MicronSweep System by Vileda and the Mop King System.

# Application Techniques

Figure 1. Proper Surface Cleaning



# Bucket Systems



- Mop King Jr.
- <http://www.am-king.com/mopkingjr.htm>

- Stainless steel
- Battery operated and electronically monitored
- Holds 15 Rayon or Microfiber flat mops
- Holds 1.5 gal solution
- Dispensed with the precise amount of solution
- Fits on housekeeping cart
- Flat mops guided along rail to a wetting tray
- Pump activates, dispenses solution to mop head

AmKing Technologies, Bedford, NH



## MicronSweep system by Vileda Professional and Micronclean ([www.micronsweep.com](http://www.micronsweep.com))



# CE Duo

## Features and Benefits

- Combines microfiber and foam technologies  
You get disinfection and removal in the same tool. 99.99% reduction in surface bacteria without disinfectant.
- Two sided cleaning tool  
Doubles the floor space cleaned with each bucket dip.
- Only mop system that will clean floors, walls and ceilings  
Eliminates the cost and inefficiency of maintaining multiple systems.
- Lightest and most ergonomic tool on the market  
Reduces fatigue and potential for muscle strains.

Courtesy of Vileda Professional



# Two & Three Bucket Systems



Courtesy of Micronova Mfg.

# Commonly Used Equipment



Courtesy Micronova Mfg.



# Latest Equipment

Isolator Tool

Courtesy of Micronova Mfg.



Lyo Tool





- [illegible]

# Product Selection Criteria

- How to choose???
  - Performance – may need multiple products
  - Substrate compatibility
  - Cleaning ability
  - Change Control
  - Globally Available
  - Supply Chain
  - Disaster Response Plan
  - Ease of application
  - Validatability
    - SDS, COA available
    - Stability Studies (Opened Container, Closed Container, Use Dilution)
    - Toxicity Studies, Analytical Methods
  - Application and contact time requirements



# Cleaning and Disinfection Best Practices

- How often to clean???
  - Environmental cleaning frequency determined by:
    - ISO Classification of area
    - The level of risk
    - Activity level in area or use
    - Environmental monitoring feedback
    - Type of process being performed & equipment used



# Sporicide: Application

- Sporicidal agent
  - Rationale
    - Weekly
    - Monthly
    - Quarterly
- Should be written in SOP's
  - Extraordinary Cleaning
  - Used Based on Risk
  - Fungal and Bacterial Spore Outbreaks

# CNC (Controlled Not Classified) Area Cleaning Frequency

- Hallways and Floors ---Mop daily ---Rinse as needed
- Walls and Ceilings---Mop monthly—Rinse as needed
- Equipment (carts, racks, trash receptacles, etc.)---Wipe weekly---Rinse as needed
- **Rinsing** is based on visual observation and safety



# Grade D (ISO 8 at rest)

Surface	Method	Cleaning Agent	Frequency	Rinse
Floors <ul style="list-style-type: none"> <li>• Around Drains</li> <li>• Foot Traffic Paths</li> <li>• Spill Areas</li> <li>• Access Ports</li> </ul>	Mop	Disinfectant with surfactant	Daily at shutdown, between process changeover	Not necessary after each application†
Walls, Ceilings <ul style="list-style-type: none"> <li>• General</li> </ul>	Wipe or Mop	Disinfectant with surfactant	Monthly	Not necessary after each application†
<ul style="list-style-type: none"> <li>• Doors, Handles, High-Traffic Areas</li> </ul>	Wipe or Mop	Disinfectant with surfactant	Daily	
Equipment <ul style="list-style-type: none"> <li>• Adjacent to Access Port</li> </ul>	Spray or Wipe	Disinfectant with surfactant	Daily during processing	As needed to remove residue buildup
<ul style="list-style-type: none"> <li>• Surface Upstream Airflow Path to Process Opening</li> </ul>			Weekly	
Other Surfaces <ul style="list-style-type: none"> <li>• Sinks</li> <li>• Benches</li> <li>• Trash Containers</li> </ul>	Wipe	Disinfectant with surfactant	Daily	Not necessary after each application†

A sporicidal agent must be used quarterly, semi-annually or as needed in response to microbial monitoring.<sup>5,6</sup>

† Any contamination control program should incorporate a residue removal component. See the Residue Removal Section for details.

# Grade C (ISO 7 at rest, ISO 8 in operation)

Surface	Method	Cleaning Agent	Frequency	Rinse
Floors <ul style="list-style-type: none"><li>Normal Traffic Paths</li></ul>	Mop	Disinfectant with surfactant	Daily after transfers	As needed to remove residue buildup
<ul style="list-style-type: none"><li>Proximity to Open Process or Transfer Areas</li></ul>		Disinfectant with surfactant followed by a sporicide	Weekly or monthly, if necessary	
Walls <ul style="list-style-type: none"><li>General</li></ul>	Wipe or Mop	Disinfectant with surfactant followed by a sporicide, if necessary	Weekly or monthly	
<ul style="list-style-type: none"><li>Door Plate</li></ul>		Disinfectant with surfactant	Daily	
Equipment <ul style="list-style-type: none"><li>Shelving</li><li>Portable Tanks</li><li>Processing Items</li></ul>	Spray or Wipe	Disinfectant with surfactant	Before and after use	
<ul style="list-style-type: none"><li>Carts (wheels)</li></ul>		Sporicide		
Other Surfaces <ul style="list-style-type: none"><li>Furniture</li></ul>	Spray or Wipe	Disinfectant with surfactant	Daily	
<ul style="list-style-type: none"><li>Chair (wheels)</li></ul>		Sporicide		

# Grade A (ISO 4.8) or B (ISO 5 at rest, ISO 7 in operation)

Surface	Method	Cleaning Agent	Frequency	Rinse
External Hoods <ul style="list-style-type: none"> <li>• Back, Sides, Top</li> </ul>	Wipe	Sterile disinfectant with surfactant	Daily	Sterile WFI or 70% IPA as needed to remove residue buildup
<ul style="list-style-type: none"> <li>• Door, Sliding Panel</li> </ul>	Wipe	Sterile disinfectant with surfactant	Daily	
		Sterile Sporicide	Weekly or in response to microbial monitoring	
Inside Hood or Curtain <ul style="list-style-type: none"> <li>• Work Surface</li> <li>• Sidewalls</li> <li>• Apparatus/Critical Surfaces</li> </ul>	Wipe	Sterile disinfectant with surfactant	Daily, preuse and postuse	
		Sterile Sporicide	Weekly or in response to microbial monitoring	
<ul style="list-style-type: none"> <li>• Curtains</li> </ul>	Wipe or Mop	Sterile disinfectant with surfactant	Daily	
		Sterile Sporicide	Weekly or in response to microbial monitoring	
Adjacent Flooring and Walls	Mop	Sterile disinfectant with surfactant	Daily, between lots and shifts	
		Sterile disinfectant with surfactant followed by a sterile sporicide, as necessary	Weekly or in response to microbial monitoring	

# Recommended Frequency

	Daily	Weekly	Monthly	Yearly
<b>Controlled Area</b>				
Floors	X	X		
Ceilings				X
Walls			X	
Fixtures/Equipment			X	
<b>Class 100,000 (ISO 8)</b>				
Floors	X			
Ceilings				X
Walls			X	
Fixtures/Equipment		X	X	
<b>Class 10,000 (ISO 7)</b>				
Floors	X			
Ceilings			X	X
Walls		X		
Fixtures/Equipment	X			
<b>Class 100 (ISO 5)</b>				
Floors	X			
Ceilings	X			
Walls	X			
Fixtures/Equipment	X			

# Cleaning SOP development

	Daily (Scheduled working days)		Weekly (Every 7 days ±3 days)		Monthly (Every 30 days ± 10 days)			Semi-Annual (Every 189 days ± 30 days)	Annual (Every 365 days ± 30 days)
Cleaning Agents	LpH Or Vesphene	70% IPA	LpH Or Vesphene		LpH, Vesphene or * 70% IPA	LpH Or Vesphene	SporKlenz	LpH Or Vesphene	LpH Or Vesphene
Surfaces	Floors	High contact areas	Floors	Walls	Fixtures/ Furniture/ Equipment and High contact areas	Walls	Floors	Walls	Ceilings
ISO Class 8 Rooms									
Equipment Prep Room 110	D	D			M	M	M		A
Wipe Down Room 112	D	D			M	M	M		A
Clean Corridor Room 114	D	D			M	M	M		A
Fill Room 3/Pre-IR Room 117	D	D			M	M	M		A
Gowning Room 122	D	D			M	M	M		A
ISO Class 7 Rooms									
**Clean Corridor Room 109	D	D		W	M		M		A
Fill Room 1 Room 115	D	D		W	M		M		A
ISO Class 5 Laminar Flow Hood									
Laminar Flow Hood Room 115	Clean before and after each use and weekly (7 days ±3 days) if not in use during the week.								
Unclassified Rooms									
Packaging Room			W		M			S	A

\*70% IPA is routinely used on glass, stainless steel, mirrors, racks and sinks.

\*\* Clean Corridor is an ISO 8 to ISO 7 transition area due to gowning area into Fill Room 1.

# Hoods, Cabinets and Benches

Clean and Disinfect prior to and after use

Spray with cleaner, then wipe: top to bottom  
and back to front, include all sides and  
work surface

Take care not to wet filter media

Following cleaning, disinfect with a sporicidal  
agent

Spray work surface and sides and keep wet for  
validated contact time

Following sporicide, wipe down with 70% IPA  
and dry wipe to remove residues



**Note:** Cleaning frequency depends on the  
process. Normally only disinfection is needed.

# Non-Product Contact Surfaces

## Precautions:

If in close proximity to product contact surfaces



- Eliminate residues carefully
- Inadvertent transfer to product contact surface
- Residues are possible source of contamination

**Note:** Disinfectants that leave no residual should be employed OR use a rinse step with IPA/WFI after disinfectant application for critical, near product contact parts.

# Non-Structural Cleanroom Surfaces


## Routine:

- Tanks, Carts, Racks, Bins, Stairs, Tubing/Pipes (Exterior), Monitors, Samplers, Tools

## Hard to Clean:

- Tops of doors, Tracks, Conveyors, Phones, Underside of tanks/carts, Wheels

**Frequency: Dependent upon classification and process**



## Procedure dependent upon where tool is used



- Consider whether materials can withstand disinfection or sterilization
  - Electronics, materials, or gaskets
- Sterilize if you can
- Otherwise, clean, disinfect, wipe with alcohol

# Drains

## Do not place drains in Grade A or B areas

- Limit to Grade C and D

## Cap drains if possible

## Routine interior disinfection difficult

- Cannot assure wetting of all surfaces
- Biofilm prevents penetration, and returns quickly

## Disinfect exterior with sporicide (bleach, hydrogen peroxide/peracetic acid)



# PDA TR # 70: Drain Cleaning

*“Drains will most probably incorporate a **biofilm** on the inside of the drain that would prevent penetration of the disinfecting agent through the biofilm and from contacting the drain surface. Disinfecting the exterior of the drain’s visible surface with sodium hypochlorite or peracetic acid and hydrogen peroxide may reduce bioburden, but such bioburden is expected to return within a short time period.”*

- PDA TR #70.

# Disinfectant Rotation & Rinsing

# Cleaning and Disinfection: Rotation

- Alternation of antimicrobial actives
  - Two disinfectants in sequence, regular rotation, with sporicidal agent as needed
  - One disinfectant daily, with sporicidal weekly or monthly



- USP 41 <1072> Disinfectants and Antiseptics
  - *“The development of microbial resistance to antibiotics is a well-described phenomenon. The development of **microbial resistance to disinfectants is less likely to occur** at significant levels, as disinfectants are more powerful biocidal agents than antibiotics.”*

# Disinfectant Rotation: ANVISA

## Article 315

Item 1: "these areas should be cleaned and sanitized frequently in accordance with a specific program approved by Quality Assurance."

Item 2 says "the areas should be monitored regularly to detect the emergence of resistance microorganisms".

## Cleaning and Disinfection: Disinfectant Rotation

**“Where disinfectants are used, more than one type should be employed. Monitoring should be undertaken regularly in order to detect the development of resistant strains.”**

**MHRA - Rules and Guidance for Pharmaceutical Manufacturers and Distributors. (2018 Draft Doc.)**

# Cleaning and Disinfection: Rotation

- Martinez, JE. The rotation of disinfectants principle: true or false? Pharmaceutical Technology (2009), p 69
  - *“Rotation of a common disinfectant and a sporicidal helps ensure that bacterial spores do not take hold in manufacturing and aseptic areas. But the rotation of common disinfectants such as those based on phenol- derivatives, aldehydes, and oxidizing agents has no scientific basis.”*

- PDA TR No. 70 2015

*“The antimicrobial agents typically employed in cleanrooms continue to be effective because they have numerous effects on a number of aspects of cellular physiology. That means multiple mutations would be required in a short period of time (ex. 5 minutes) with exposure to low numbers of cells typically found in a cleanroom to overcome their detrimental effects. As such, resistance of a cell to agents used in a disinfection process would be highly unlikely given the environmental conditions and low cell number.”*

# Cleaning and Disinfection: Rotation

## PDA TR No. 70

*“Given this knowledge, the pharmaceutical and biotechnology **industries have moved away from the rotation of two disinfecting agents.** This formerly common practice led to high residue levels and subordinate efficacy performance. Today most firms use a system whereby a **disinfectant is rotated with a sporicide to more effectively reduce the bioburden** levels. The rotation of a disinfectant with a sporicide is **superior to the use of rotations of multiple disinfectants.**”*

# Cleaning and Disinfection: Rotation

- USP 41 <1072> Disinfectants and Antiseptics
- Annex 1 (Draft 2018) and MHRA Orange Guide (2016)
- FDA Aseptic Processing Guide (2004)
- FDA, MHRA, HPRA, CFDA, ANSM, ANVISA, CFDA, FDAHA, Swissmedic, & EMA Expectations
- Industry Articles (Ex. Scott Sutton, Jose Martinez, Richard Prince, Rebecca Smith)
- PDA Cleaning and Disinfection TR #70 (2015)
- PDA TR #69 on Biofilms (2015)
- The CDC Handbook - A Guide to Cleaning & Disinfecting Cleanrooms (Tim Sandle 2018)
- A Guide to Disinfectants and their use in the Pharmaceutical Industry (Pharmig 2017)
- USP 41 <1116> Microbiological Control and Monitoring of Aseptic Processing Environments
- PIC/S Guide to Good Practices for the Preparation of Medicinal Products in Healthcare Establishments (2014)
- WHO Annex 6
- PHSS Technical Monograph #20 “Bio-contamination characterization, control, monitoring and deviation management in controlled/GMP classified areas

# Cleaning and Disinfection: Rinsing

## Do I need to rinse?

### 483 observations (2013)

- Your firm does not always keep laminar flow hoods visually clean of residue on HEPA filter surfaces and covering grates.....I observed **white and yellow residue** on the HEPA filters.....and in areas up to approx. eight inches square on the filter.....
- I observed **white particles** on the floor of the clean room...approximately two to three millimeters square.
- Recent WL reference:  
<https://www.fda.gov/iceci/enforcementactions/warningletters/2017/ucm558496.htm>
- Dr. Sharon Thoma's view on residues




# Cleaning and Disinfection: Rinsing

- Rinse as needed to control residue
  - Appearance
  - Functionality – sticky or opaque surfaces
  - Product risk
  - Interaction/interference with other chemical agents being used
  - Safety issue (stickiness, tackiness, slippery)
- Rinse agents
  - Alcohols or Water
  - Cleaners: Acidic, Basic or Neutral (low concentrations)
  - Periodic rinsing based on aesthetics and safety
- **Annex I Draft: Cleaning programs should be effective in the removal of disinfectant residues.**





This is a  
problem?  
Why? We  
clean the  
door all the  
time...

# Surface Types and Topography



- Sticky mats
- Drains
- Edges and corners

# Surface Conditions Effect Performance



Courtesy Bruce Ritts

# PDA TR # 70: Conducting Investigations related to Cleaning and Disinfection

## **Common Causes:**

- Application issues**
- Dilution issues**
- Insufficient contact times**
- Expired product**
- Incorrect biocide for cleanroom bioburden**
- Lack of adherence to protocols**
- Equipment issues (rusting and pitting)**
- Using inadequate cleanroom tools**

**[jim\\_polarine@steris.com](mailto:jim_polarine@steris.com)**

**Cell: (314) 616-9931**

**Office: (314) 290-4793**